




MOBILE CLOTHES AIRER HOOK REPLACEMENT - INSTRUCTION SHEET.

IMPORTANT: READ THESE INSTRUCTIONS BEFORE ASSEMBLY AND USE.



HOOK REPLACEMENT INSTRUCTIONS.

IMPORTANT: *Protect your eyes* from possible flying plastic when removing the Hook.

TO REMOVE:

- Open the Airer.
- Using a small screwdriver, pry out the old Hook taking care to protect your eyes and the painted frame. See **FIG 1.**

TO REPLACE:

- Line up the new Hook with the locating hole in the frame. Ensure that the Hook is the correct way up. See **FIG 1a.**
- Snap the new hook into position.

HOOK REPLACEMENT PACK CONTAINS:

DESCRIPTION	QTY.
Hook	4